

Additional Notes to the VSI/C2 User's Manual

Section	Notes
3.7	The filtering of Cass 2 messages is disabled by default at power up.
3.8	The default state of the SXR connection to the ALDL pins at power up should be stated.
3.10	The A/D converter is disabled by default at power up
3.12	The default state of latency time enabling/disabling at power up is disabled
3.13	The UART mode is disabled by default at power up

Dearborn Group, Inc.

(248) 488-2080 | (248) 488-2082 FAX | dg@dgtech.com

Copyright © 2002 Dearborn Group Inc.