





SECURE FIRMWARE SOLUTION

User Guide


1. Download the latest drivers for the VSI NxGen PLUS from www.dgttech.com/downloads or use “DG Update” from the Start>DGTech Utilities>DG Update. The drivers will include the Secure Firmware Solution application. Begin installation:



2. Once installed, locate the Secure Firmware Solution application. To locate:
 - a. Search for ‘Secure Firmware Solution’ on your Taskbar Search window, or
 - b. Go to: Start>DGTech VSI NxGen PLUS>Secure Firmware Solution
 - c. Open the application.



3. A Truck-Connect account is required for the VSI NxGen PLUS device.
 - a. If you already have a Truck-Connect account, enter that email and password, select "Sign In", then skip to step 9.
 - b. To create a Truck-Connect account, select 'Create Account' link and proceed below.



SECURE
Firmware Solution


Email

Password

[Create Account](#) [Forgot Password](#)

EXIT **SIGN IN**

4. On the register page, enter your Email and Company Name, or the name associated with the email, and select 'CONTINUE'.



TRUCKCONNECT [SCHEDULE A CALL](#) [CUSTOMER LOG IN](#)

Thank you for choosing DG Technologies Secure Firmware Updater.

To register, complete the form below. A confirmation email will be sent to the address you provide.


If you are already subscribed to another Truck-Connect.com service, no additional registration is needed. Simply log into the Secure Firmware Updater application using your Truck-Connect.com email and password.

Enter your Email and Company Name below to register for the Secure Firmware Updater application.

Email Company Name

CONTINUE

5. Enter the required information on the next page and select 'REGISTER'.




A registration form with fields for First Name, Last Name, Address Line 1, Address Line 2 (Optional), Country, City / Town, State / Province, Zip / Postal Code, and Phone Number. A red arrow points to the 'REGISTER' button at the bottom right.

6. An email will be sent to the email provided with instructions regarding next steps to enable your account. Go back to the log in at Truck-Connect.com in steps 2 & 3, and input this temporary password provided.


Someone in your organization has invited you to join the Truck-Connect account. Please visit www.truck-connect.com to get started. Your username is [REDACTED] and temporary password is [REDACTED]

7. Once logged in, follow the steps on the ensuing screen to change your password. You are now registered with Truck-Connect.
8. Go back to the Secure Firmware Solution application, enter your credentials, and select 'SIGN IN'.




A sign-in form with fields for Email and Password. Below the fields are 'Create Account' and 'Forgot Password' links. At the bottom are 'EXIT' and 'SIGN IN' buttons. Red arrows point to the 'Email' and 'Password' fields, and another red arrow points to the 'SIGN IN' button.

9. Follow the steps shown and select 'UPDATE' in the bottom right-hand corner to begin:



10. Once 'UPDATE' is selected, a progress bar will appear and show that the device update is in progress.



11. Once the message showing 'The device has been updated' appears. Select 'OK' and exit out of the application. Your device is now securely updated to the latest version.

